

Installation-Assembly Instructions

Sovereign Big & Tall High-Back Bonded Leather Chair

The assembly process is shown in six steps:

- Attaching castors (1) to the 5-star base (2).
- Attaching the seat cushion (5) to the mechanism (4) using screws (8) and an Allen key (11).
- Attaching the back cushion (6) to the mechanism (4) using screws (10) and an Allen key (11).
- Attaching the armrests (7) to the chair frame using screws (9) and plastic caps (12).
- Inserting the gas lift (3) into the seat cushion (5).
- The final assembled chair.

① CASTOR	② 5-STAR BASE	③ GAS LIFT	④ MECHANISM	⑤ SEAT CUSHION	⑥ BACK CUSHION	⑦ ARMREST	⑧ SCREW 5/16"×1"	⑨ SCREW 3/8"×2"	⑩ SCREW 3/8"×1-1/2"	⑪ ALLEN KEY	⑫ PLASTIC CAP
											
5 PCS	1 PC	1 PC	1 PC	1 PC	1 PC	1 PAIR	4 PCS	4 PCS	4 PCS	1 PC	4 PCS

Installation-Assembly Instructions

Sovereign Big & Tall High-Back Bonded Leather Chair

